

SECURITY SYSTEM APP QUICK START GUIDE



TuyaSmart

Scan the QR code or find
"TuyaSmart" on APP Store or
Google Play to get free APP.

LOG IN

Upon download and installation of App on your phone, please follow the on-screen prompts to register and login to add your hub.

ADDING YOUR HUB

1. Smartlink Configuration

- ↓ Tap **Add Device** or "+", select **Security & Sensor** and tap **Alarm**.
- ↓ On your hub, tap √ to go to **Wi-Fi > Smartlink Configure**, make sure your device is in SmartLink mode with LED is blinking rapidly.
- ↓ Tap **Confirm indicator rapidly blink**, choose your local Wi-Fi and input password(Only 2.4Ghz Wi-Fi network is supported).
- ↓ Wait the configuration finishes, tap **Done**.

2. SoftAP Mode

- ↓ Please change to Soft AP mode if the configuration fails in SmartLink mode.
- ↓ Tap **AP Mode** at **Add Device** page.
- ↓ On your hub, tap √ to go to **Wi-Fi > SoftAP Configure**, make sure your device is in SoftAP mode with LED is blinking slowly.
- ↓ Tap **Confirm indicator slowly blink** on your APP, choose your local Wi-Fi and input password(Only 2.4Ghz Wi-Fi network is supported).
- ↓ Tap **Confirm > Go to Connect**, then choose the Wi-Fi hotspot named "Smartlife-XXXX" in your Wi-Fi list. Go back to your APP to wait the Wi-Fi configuration finishes, then tap **Done**.

Tips: after the configuration is done, you might tap  > **Share Device** to share your hub with your family.

HOW TO ADD PHONE NUMBER

- ↓ Tap **Setting > Alarm call number** in Contact column to add phone numbers for alarm call.
- ↓ Tap **Setting > Alarm SMS number** in Contact column to add phone numbers for alarm SMS.
- ↓ Tap **Alarm call** to turn alarm call on or off.
- ↓ Tap **Alarm SMS** to turn alarm SMS on or off.

Tips: up to 5 alarm call numbers and 5 alarm SMS numbers can be added.

HOW TO ADD ACCESSORY

Pick your device at home page, tap **Accessories > Add**, then follow below tips to trigger your accessory to be added (After the accessory is added, it will be classified to each corresponding column automatically)

To	Do like this before the hub sniffer countdown expires	
Add a wireless sensor	Press the panic button or separate the sensor from the magnet by at least 1.0 inches(2.5 cm)	
	Press the pairing button or trigger it with an motion	
Add a remote Tag	Press any button on your remote tag	
Add a RFID tag	Tap RFID Tag on the RFID read zone on your hub	

Tips: up to 100 wireless detectors, 10 remote tags and 10 RFID can be added,

EXIT / ENTRY DELAY

Change Delay Value

Tap **Exit delay** or **Entry delay** to change the delay time

Tips: default exit delay is 40 seconds and entry delay is 30 seconds

HOW TO ARM/DISARM

Tap  to Away arm

Tap  to Home arm.

Tap  to Disarm

Tap  to trigger an emergency alarm.

Tips: tap **Setting > Timer** to arm/disarm your system on schedule.

More details about using your security system, please refer to USER'S GUIDE.